V-028PU User Guide v2.qxd:V-0268PU User Guide 12/3/08 09:14 Page 1

Vax careline
0870 6061248

Carpet washer

PowerJet PET
CARPET WASHER

Vax model number:
V-028PU



instruction manual

www.vax.co.uk

Please read carefully before using this cleaner.
Always fully extend the mains cable before use.
Retain for future reference.

V-028PU User Guide v2.qxd:V-0268PU User Guide 12/3/08 09:15 Page 2

1. Diagram

V-028PU



Fig.1/1

1. Handle
2. Clean water tank latch
3. Clean water tank
4. Dirty water tank latch
5. Dirty water tank handle
6. Brushbar
7. Dirty water tank
8. Dirty water tank door
9. Dirty water tank lid
10. Solution tube clip
11. Power cord
12. Lower cord clip
13. Lower cord wrap with quick cord release
14. Power on/off pedal
15. Solution tube port
16. Handle release pedal
17. Tool caddy
18. Carry handle
19. Cord wrap
20. Vax Ultra Solution
21. Vax Spot and Stain Remover
22. Hose wrap
23. Solution tube
24. Upholstery/stair hose adaptor
25. Upholstery/stair hose
26. Upholstery/stair attachment
27. Solution spray trigger
28. 8x Screws
29. Power wash brush
30. 4x AA bateries for power wash brush
31. Power wash brush parking caddy

V-028PU User Guide v2.qxd:V-0268PU User Guide 12/3/08 09:15 Page 3

2. Safety Information

FOR HOUSEHOLD USE ONLY.

When using the vacuum cleaner, basic safety precautions should always be observed, including the following:

1. Do not leave the carpet washer unattended when plugged in. Unplug it from socket when not in use.
2. To prevent electric shock do not use outdoors.
3. Not to be used as a toy. Children should be supervised to ensure that they do not play with the appliance.
4. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
5. Use only as described in this manual.
6. Do not use with a damaged cord or plug. If the supply cord and/or plug is damaged, they must be replaced by the manufacturer, a Vax Service Agent or similarly qualified persons in order to avoid hazard.
7. Do not pull or carry by the cord, use the cord as a handle, allow the cord to come into contact with hot or sharp surfaces or close a door on the cord.
8. Do not unplug by pulling on the cord.
9. Do not handle the plug or carpet washer with wet hands.
10. Do not put any objects into openings or operate with openings blocked, keep them free of anything that may reduce airflow.
11. Keep hair, loose clothing, fingers and all parts of the body away from openings and moving parts.
12. Do not use the carpet washer on any glowing, burning or smoking particles.
13. Do not use without the solution tank and dirty water tank in place.
14. Do not use the vacuum without the dust bag in place.
15. Turn off all controls before unplugging.
16. Do not use to pick up flammable or combustible liquids such as petrol, or use in areas where they may be present.
17. Keep the unit on the floor.
18. Do not use an extension cord.
19. Do not attempt to remove blockages with sharp objects as they may cause damage.
20. Store indoors put away after use to prevent tripping accidents.
21. Using improper voltage may result in damage to the motor and possible injury to the user. The correct voltage is listed on the rating label.
22. A hazard may occur if the carpet washer runs over the power supply cord.
23. To prevent dirty water from running into motor, do not hold the appliance upside-down or lay on its side. Use appliance in normal vacuuming position.
24. Use extra care when cleaning on stairs.
25. Do not carry appliance while motor is running.

NOTE: Carpets should be dry vacuumed thoroughly before washing.

NOTE: The unit must be unplugged from the mains socket outlet after use, and before cleaning or maintaining the unit.

⚠ IMPORTANT: This unit is not intended for commercial use.

PLEASE KEEP THESE INSTRUCTIONS FOR FURTHER USE.

V-028PU User Guide v2.qxd:V-0268PU User Guide 12/3/08 09:15 Page 4

3. Assembly

Putting your cleaner together

Stand base in upright position. Push mid-section onto base by aligning tabs on inside of mid-section with the pockets on the base (Fig.3/1)



Fig.3/1

Insert 4 lower handle/tool caddy screws (as shown) and tighten until secure (Fig.3/2).


Fig.3/2 back view

Slide upper handle down onto unit (Fig.3/3).



Fig.3/3

Insert the upper handle screw (as shown) and tighten until secure (Fig.3/4).

NOTE: Make sure the power cord is out of the way to avoid pinching.


Fig.3/4 back view

Caddy Assembly

Align tool caddy with screw holes on mid-section and base (Fig.3/5).


Fig.3/5

Insert the three (3) tool caddy screws and tighten until secure (Fig.3/6).


Fig.3/6

V-028PU User Guide v2.qxd:V-0268PU User Guide 12/3/08 09:15 Page 5

Cord Storage

Wrap cord around upper and lower cord wraps (Fig.3/7).

Clip plug to cord to secure for storage.



Fig.3/7

Tool Storage

Place Upholstery/Stair hose adaptor, Upholstery/Stair hose, and the Upholstery/Stair attachment into their storing locations (Fig.3/8).



Fig.3/8

Slide the adaptor end of hose into the left clip on tool caddy (Fig.3/9).



Fig.3/9

Run hose from the tool caddy to the upper hose wrap and press into hose clip A (Fig.3/10).



Fig.3/10

Continue wrapping hose clockwise, aligning hose into groove on the bottom hose clip (Fig.3/11).



Fig.3/11

Wrap hose back to the upper hose wrap and press into hose clip B (Fig.3/10).

Slide upholstery tool attachment handle into the right clip of the tool caddy (Fig.3/12).



Fig.3/12

V-028PU User Guide v2.qxd:V-0268PU User Guide 12/3/08 09:15 Page 6

4. Operation

Preparing the Carpet

⚠ IMPORTANT: Do not use the carpet washer as a dry vacuum.

1. Vacuum carpet thoroughly. Use a vacuum cleaner with a revolving brushbar for best results.
2. Remove as much furniture from the room as possible. If unable to remove the furniture, place plastic or foil under and around the legs until the carpet has dried completely.

Helpful hints for cleaning carpet:

1. Only use Vax Ultra Solution with this carpet washer.
2. Do not oversaturate carpet with cleaning solution while using the carpet washer.
3. For heavily soiled areas, additional applications may be necessary.
4. Allow plenty of time to dry carpet thoroughly.
5. Wipe cleaning solution from woodwork and wood to prevent any damage.
6. Try not to walk on carpet until it is completely dry.
7. After carpet is thoroughly dry, vacuum the carpet using a vacuum cleaner with a revolving brushbar.
8. Before cleaning, determine where to start and end, making sure not to walk over previously cleaned areas.

Check for colour fastness:

Before cleaning carpet, test for colour fastness. Dampen a white cloth with solution. Test a small area in an inconspicuous area. Gently rub the cloth over the area. Check each colour for colour bleeding. If the cloth remains clean, it should be safe to clean the carpet.

After cleaning:

- Allow carpet to dry completely. Try not to walk on the carpet until it is dry.
- If it is necessary to walk on the carpet, place white towels on the areas to be walked on.
- If the carpet is not dry and the furniture must be placed back in the room, use plastic or foil under the furniture to prevent staining the carpet.
- Thoroughly clean the dirty water tank with warm (max 40°C) tap water.

How to Operate

Grasp clean water tank under handle while pressing clean water tank latch. Tilt clean water tank away from cleaner and remove (Fig.4/1).



Fig.4/1

Unscrew measuring cap from back side of clean water tank (Fig.4/2).


Fig.4/2

Fig.4/5

Fill measuring cap with solution (approximately 5 capfuls). Pour into clean water tank (Fig.4/3).

NOTE: Use only Vax Ultra solution.

Using other cleaning solutions may cause excess foaming.

Excessive foam will cause the float to shut off the carpet washer prematurely. Using other solutions will void the warranty.


Fig.4/3

Fig.4/6

V-028PU User Guide v2.qxd:V-0268PU User Guide 12/3/08 09:15 Page 7

Carpet Cleaning

Fill remainder of clean water tank with warm (max 50°C) tap water. Replace cap (Fig.4/4).



Fig.4/4

Place bottom of clean water tank into carpet washer and rotate top into position until the clean water tank Latch snaps into place (Fig.4/5).



Fig.4/5

Plug cord into electrical socket. Step on the power on/off pedal to turn cleaner on (Fig.4/6).

NOTE: Never leave unit unattended with power on. Turn off when emptying and filling tanks.

Do not oversaturate the carpet.



Fig.4/6

Step onto handle release pedal to put into cleaning position (Fig.4/7) .



Fig.4/7

to whilst depressing solution spray trigger, push carpet washer in a forwards motion. Release trigger and pull unit backwards in same path to remove dirty water and solution from the carpet.

(For heavily soiled areas, repeat if necessary) (Fig.4/8).

⚠ IMPORTANT: For best cleaning results use a steady, moderate, forward and backward motion.

⚠ IMPORTANT: If the sound of the motor changes to a high pitch, this indicates the dirty water tank is full and must be emptied.



Fig.4/8

cleaning upholstery and stairs

Put carpet washer in its upright position, then turn off (Fig.4/9).



Fig.4/9

V-028PU User Guide v2.qxd:V-0268PU User Guide 12/3/08 09:15 Page 8

Remove the dirty water tank door from the top of the dirty water tank (Fig.4/10).



Fig.4/10

IInsert the up-holstery/stair hose adaptor into the opening on top of the dirty water tank (Fig.4/11).



Fig.4/11

Connect the hose solution tube into the fitting on the lower left side of handle facing carpet washer (Fig.4/12).



Fig.4/12

Upholstery / stair attachment

Step on power on/off pedal to turn cleaner on.

While depressing solution spray trigger, pull attachment in backward motion.

Release trigger and push attachment forward in the same path to remove dirty water and solution from upholstery. (For heavily soiled areas, repeat if necessary.) (Fig.4/13).

NOTE: Do not oversaturate the upholstery.

⚠ IMPORTANT: For best cleaning results use steady, moderate, forward and backward motion. Make sure upholstery is dry before use.

NOTE: If the dirty water tank door is not replaced, there will be no suction through the nozzle and the unit will not operate properly.



Fig.4/13

Power Wash Brush usage

Step on power on/off pedal to turn cleaner on.

Press the button at the back of the Power Wash Brush to start the rotation of the brushes.

To release the flow of water and solution, press the trigger and then move the tool in slow circular motions over the desired area (Fig.4/14).

NOTE: After depressing the trigger there will be a short time delay before water is dispensed.

NOTE: Although the tool is continually extracting water from the carpet while switched on, positioning the front nozzle directly onto the area will allow better recovery and aid drying.

⚠ IMPORTANT: For first use, there may be a 10-15 second delay between depressing the trigger/button and water being released from the attachments. This is normal and is not a fault.



Fig.4/14

NOTE: Battery installation required for powered wash brush

V-028PU User Guide v2.qxd:V-0268PU User Guide 12/3/08 09:15 Page 9

Emptying and cleaning the dirty water tank and filter

The carpet washer is equipped with a shut off valve within the dirty water tank. When the dirty water tank becomes full, the float will rise, shutting off the air flow through the nozzle.

NOTE: The float in the carpet washer will shut off the suction when the dirty water tank is full. For best results, use smooth, steady motion keeping the nozzle flat against the carpet. Tipping the carpet washer and breaking the seal of the nozzle and carpet will cause the float to rise and shut off the suction. Once the float is activated, empty the dirty water tank. If the dirty water tank does not appear full, press the Power on/off pedal and wait for the float to settle and reset. If the float repeatedly shuts off the suction, empty the dirty water tank. For best results, use only Vax Ultra solution. Other solutions may generate excessive foam which will cause the float to rise prematurely and shut off the suction. Use 5 (five) capfuls of Vax ultra per fill up of the clean water tank. A higher concentration of carpet cleaner may cause excessive foaming.

NOTE: There will be a noticeable change in the pitch of the cleaner. This indicates a need to empty the dirty water tank.

⚠ WARNING: To reduce the risk of injury from moving parts - unplug before emptying the dirty water tank.

Grasp top of dirty water tank handle and push latch to release (Fig.4/15).



Fig.4/15

Grasp handle and pull tank out of base (Fig.4/16).


Fig.4/16

Remove dirty water tank lid (Fig.4/17).


Fig.4/17

To empty dirty water tank, grasp handle with one hand and nozzle with the other and empty into sink. To clean, rinse tank thoroughly with clean water and let dry (Fig.4/18).


Fig.4/18

Remove filter from rear of dirty water tank lid (Fig.4/19).


Fig.4/19

V-028PU User Guide v2.qxd:V-0268PU User Guide 12/3/08 09:15 Page 10

Rinse dirty water tank and filter with warm tap water. Wipe and let dry thoroughly before storing to prevent mildew from forming (Fig.4/20).

NOTE: Do not use any chemicals when cleaning.



Fig.4/20

Replacing dirty water tank in base of carpet washer

While making sure the front of the dirty water tank is resting on the base, place the rear of the tank into the base of the cleaner (Fig.4/21).



Fig.4/21

Push handle down until it latches (Fig.4/22).

NOTE: Do not store cleaner with solution in reservoir or dirty water in dirty water tank. Mineral deposits and mildew can form which will affect the performance of the carpet washer.



Fig.4/22

5. Maintenance

Transporting & storing carpet washer

Put handle in upright locked position (Fig.5/1).



Fig.5/1

Turn unit off. Store cord and above floor cleaning attachments if used.

Tilt unit back on rear wheels and push forward (Fig.5/2).



Fig.5/2

NOTE: The unit can also be transported between rooms or floors using the carry handle.

Before storing carpet washer:

1. Empty and rinse clean water tank and dirty water tank.
2. Replace empty clean water tank and dirty water tank.
3. Ensure that brushes and underside of unit are fully dry prior to storing on a carpeted or wood surface.

NOTE: Do not store unit with a full clean water tank or dirty water tank.

⚠ IMPORTANT: Do not transport the carpet washer with either the clean water tank or dirty water tank full.

V-028PU User Guide v2.qxd:V-0268PU User Guide 12/3/08 09:15 Page 11

6. Troubleshooting

⚠ WARNING: To reduce the risk of personal injury, unplug the vacuum cleaner before performing maintenance or troubleshooting checks.

PROBLEM: The cleaner won't run.	
Cause:	Not properly plugged into electrical outlet.
Solution:	Plug in firmly.
Cause:	No electricity in electrical outlet.
Solution:	Check fuse or breaker.
Cause:	ON/off switch not turned on.
Solution:	Push on/off switch to 'on'.
Cause:	Blown fuse/tripped breaker.
Solution:	Reset circuit breaker or replace fuse.
PROBLEM: Cleaner won't pick up/loss of suction.	
Cause:	Dirty water tank is full.
Solution:	Switch off and unplug cleaner. Empty dirty water tank as shown in Section 4.
Cause:	Dirty water tank not installed correctly.
Solution:	Refer to page 9 for fitting information.
Cause:	Obstruction in hose/nozzle.
Solution:	Remove hose and clear obstruction.
Cause:	Broken or worn belt.
Solution:	Replace the belt. See page 10.
Cause:	Brushbar is worn.
Solution:	Replace the brush bar. See page 10.
PROBLEM: Liquid escaping from the carpet washer.	
Cause:	Dirty water tank is full.
Solution:	Switch off and unplug cleaner. Empty dirty water tank as shown in Section 4.
Cause:	Dirty water tank not installed correctly.
Solution:	Refer to page 9 for fitting information.
Cause:	Solution tank not installed correctly.
Solution:	Make sure the tank is securely locked in place
PROBLEM: Clean solution won't dispense.	
Cause:	Solution tank not installed correctly.
Solution:	Make sure the tank is securely locked in place.
Cause:	Solution tank empty.
Solution:	Refill tank. Refer to page 6 for instructions.

7. UK Service & Help

Vax Care 0870 6061248

Monday-Friday 8.00am to 6.00pm

Saturday-Sunday 9.00am to 5.00pm

An answerphone is available outside of these hours. Any queries or concerns about using the Vax, call the Vax Careline. Calls are charged at the UK national rate.

Please make a note of the serial number and model number of the carpet cleaner before calling. There are over 400 approved Vax Service Agents in the UK. For the nearest Service Agent, please call the Vax Careline.

www.vax.co.uk

8. Technical Specification

Voltage:	220-240V ~50Hz
Wattage:	900W
Capacity:	Clean water tank - 4 litres Dirty water tank - 2.3 litres
Cord length:	7.5 metres
Weight:	8.9kg

Subject to technical change without notice.

CE

V-028PU User Guide v2.qxd:V-0268PU User Guide 12/3/08 09:15 Page 12

EEC STATEMENT OF COMPLIANCE

Manufacturer/EEC importer: Vax Limited, hereby on our own responsibility, declare that the Vax V-028PU is manufactured in compliance with the following Directives:

Safety: 2006/95/EC Low Voltage Directive
EMC: 2004/108/EC Electromagnetic Compatibility Directive

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

Vax Ltd., Kingswood Road, Hampton Lovett, Droitwich, Worcestershire, WR9 0QH, UK
email: info@vax.co.uk - website: www.vax.co.uk